

⚠ Important Notes

- Turn off the device after use. It will **NOT** turn off automatically.
- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.

Description

- ① **10-Pin Connector** – connects to Mitutoyo Digimatic data cable
- ② **Tri-Color LED**
 - – Device is on
 - – Device is in charge
 - – Device is fully charged
- ③ **USB Port** – connects to USB cable to charge
- ④ **On/Off Button** – push on and push off
- ⑤ **Trigger Connector** – 2.5 mm audio port, connects to trigger switch



Included in the box

- WiMER4A Base 1X
- Mitutoyo SPC Cable 1X
- Trigger Switch 1X
- USB Charging Cable 1X
- USB Power Adapter 1X
- User Guide 1X

Compatible Software

- iOS: MultiGage Reader
- Android: MultiGage Reader
- Windows: MultiGage Reader (BLE Dongle Required)
- iOS app can be directly downloaded from the App Store for FREE.
- Android app can be directly downloaded from the Google Play Store for FREE.
- Windows software is available on Motionics website.

Quick Start

- Turn on WiMER4A and connect to Mitutoyo Protractor.
- Plug in USB Bluetooth dongle if using Windows PC.
- Run one of the aforementioned Apps/software.
- In the main page, tap Scan/+ button to bring up a new pairing page.
- Wait for the software to finish scanning nearby devices, select **WiMERXXXX** to connect.
- Connection may take a few seconds, once paired, instrument reading shows in the software.