



## Wireless Measurement Read WiMER1 User Guide

### ⚠ Important Notes

- Turn off the device after use. It will **NOT** turn off automatically.
- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.

### Description

- ① **10-Pin Connector** – connects to Mitutoyo Digimatic data cable
- ② **Tri-Color LED**
  - – Device is on
  - – Device is in charge
  - – Device is fully charged
- ③ **USB Port** – connects to USB cable to charge
- ④ **On/Off Button** – push on and push off
- ⑤ **Trigger Connector** – connects to trigger switch



### Included in the box

- WiMER1 Base 1X
- Mitutoyo SPC Cable 1X
- Trigger Switch 1X
- USB Charging Cable 1X
- USB Power Adapter 1X
- User Guide 1X

### Compatible Software

- iOS: DialRead, DialReadPad, MultiGage Reader
- Android: Dial Reading
- Windows: Dial Reading (BLE Dongle Required)
- iOS App can be directly downloaded from the App Store for FREE.
- Android and Windows programs are available on Motionics website.

### Quick Start

- Turn on WiMER1 and connect to Mitutoyo instruments.
- Run one of the aforementioned Apps/software.
- In the main page, tap Pair button to bring up a new pairing page.
- Plug in USB Bluetooth dongle if using Windows PC.
- Wait for the software to finish scanning nearby devices, select WiMERXXX to connect.
- Connection may take a few seconds, once paired, instrument reading shows in the software.