

⚠ Important Notes

- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.

Description

- ① **On/Off Button** – press to turn unit on/off.
- ② **Hold Button** – press to hold the value on display; press again to disable.
- ③ **Tilt% Button** – press to display angle measure in tilt percentage value; press again to disable.
- ④ **Zero Button** – press to set a bevel (relative) zero; to return to level reading press on/off button for 3 seconds.
- ⑤ **LCD Display** – displays readings.
- ⑥ **Magnets** – 6 rare earth magnets (BPRO-S) or 3 rare earth magnets (BPRO-L)
- ⑦ **USB Charging Port** – used for charging.



Included in the box

- Digital Protractor 1X
- USB Charging Cable 1X
- User Guide 1X

Compatible Software

- iOS: MultiGage Reader
- Android: MultiGage Reader
- Windows: MultiGage Reader (BLE Dongle Required)
- iOS app can be directly downloaded from the App Store for FREE.
- Android app can be directly downloaded from the Google Play Store for FREE.
- Windows software is available at Motionics.com/download.

Quick Start

- Press on/off button to turn on device.
- Plug in USB Bluetooth dongle if using Windows PC.
- Run the software, tap Scan/+ button to enter pairing page.
- Wait for the software to finish scanning nearby devices, select **BProXXX** to connect.
- Connection may take a few seconds, once paired, Bluetooth Digital Protractor reading shows in the software.