

Wireless Measurement Read

WiMER1+ User Guide

Important Notes

- Turn off the device after use. It will NOT turn off automatically.
- Do NOT open the device. Opening causes permanent damage and avoids the warranty.

Description

- 1. On/Off Switch slides to turn WiMER1+ on/off
- **2. Micro USB** connects to data cable to receive signals from the measurement instrument; connects to charging cable to recharge WiMER1+
- **3. Trigger Button** records single reading in single record mode (if activated)
- 4. Antenna connects to external antenna
- 5. On/Off LED turns on blue when WiMER1+ is on

6. CHG LED – turns on red when the device is in charging. It changes to green when the battery is fully charged



Included In The Package

- WiMER1+ Base
- External Antenna
- SPC to Micro USB Data Cable
- USB Charging Cable
- USB Power Adaptor
- User Guide

Software/App

- iOS: DialRead, DialReadPad, MultiGage Reader (from App Store)
- Android: Dial Reading (from Motionics website)
- Windows PC: Dial Reading (from Motionics website, dongle required)

Quick Start

DialRead, DialReadPad

- Turn on WiMER1+ and connect it to a Mitutoyo instrument.
- Run one of the aforementioned Apps.
- In the main page, tap **Pair** button to bring up a new pairing page.
- Wait for the app to finish scanning nearby devices, tap the name **WIMERPXXX** to connect.
- Once paired, **New Measurement** button turns into dark blue. Tap it to start reading and collecting data.
- To disconnect WiMER1+, tap **Unpair** button in the main page.

MultiGage Reader (for reading from multiple devices)

- Turn on WiMER1+ or other devices and connect them to Mitutoyo instruments.
- Run MultiGage Reader App.
- In the main page, tap **Pair** button to bring up a new pairing page.
- Wait for the app to finish scanning nearby devices, select one or more devices and tap **Connect** button to connect.
- Once paired, each WiMER1+ will be assigned a panel in the main page to display its readings.
- To disconnect one WiMER1+, tap **Disconnect** button next to it.
- To add more devices, tap **Pair** button again.

Motionics, LLC 8500 Shoal Creek Blvd Building 4 Suite 209 Austin, TX 78757 www.motionics.com info@motionics.com © 2016 Motionics, LLC. All rights reserved.