

Wireless Measurement Read WiMER1+ - User Guide

Important Notes

- Turn off the device after use. It will **NOT** turn off automatically.
- Do NOT open the device. Opening causes permanent damage and voids the warranty.

Description

- 10-Pin Connector connects to Mitutoyo Digimatic data cable
- 2 Tri-Color LED
 - Device is on
 - Device is charging
 - Device is fully charged
- 3 **USB Port** connects to USB cable to charge
- 4 On/Off Button push on and push off
- 5 Trigger Connector 2.5 mm audio port, connects to trigger switch
- 6 Antenna increases WiMER1+ Range





Included in the box

- WiMER1+ Base 1X
- External Antenna 1X
- Trigger Switch 1X
- USB Charging Cable 1X
- USB Power Adapter 1X
- User Guide 1X

Compatible Software

- iOS: MultiGage Reader (download for FREE from the App Store)
- Android: MultiGage Reader (download for FREE from the Play Store)
- Windows: MultiGage Reader (BLE dongle required, download for FREE from www.motionics.com Go to Resources > Download > Software)



MultiGage Reader App iPhone/iPad

MultiGage Reader APP Android



Quick Start

- Install external antenna on WiMFR1+.
- Turn on WiMER1+ and connect to Mitutoyo instruments.
- Plug in USB Bluetooth dongle if using Windows PC.
- Run one of the aforementioned apps/software.
- In the main page, tap Scan/+ button to bring up a new pairing page.
- Wait for the software to finish scanning nearby devices, select WIMERXXX to connect.
- Connection may take a few seconds, once paired, instrument reading shows in the software.