



## Important Notes

- Turn off the device after use. It will **NOT** turn off automatically.
- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.

## Description

- ① **10-Pin Connector** – connects to Mitutoyo Digimatic data cable
- ② **Tri-Color LED**
  - – Device is on
  - – Device is in charge
  - – Device is fully charged
- ③ **USB Port** – connects to USB cable to charge
- ④ **On/Off Button** – push on and push off
- ⑤ **Trigger Connector** – 2.5 mm audio port, connects to trigger switch



## Included in the box

- WiMER1 Base 1X
- Trigger Switch 1X
- USB Charging Cable 1X
- USB Power Adapter 1X
- User Guide 1X

## Compatible Software

- iOS: MultiGage Reader (download for FREE from the App Store)
- Android: MultiGage Reader (download for FREE from the Play Store)
- Windows: MultiGage Reader (BLE dongle required, download for FREE from [www.motionics.com](http://www.motionics.com) Go to Resources > Download > Software)



MultiGage Reader App  
iPhone/iPad



MultiGage Reader APP  
Android

## Quick Start

- Turn on WiMER1 and connect to Mitutoyo instruments.
- Plug in USB Bluetooth dongle if using Windows PC.
- Run one of the aforementioned apps/software.
- In the main page, tap Scan/+ button to bring up a new pairing page.
- Wait for the software to finish scanning nearby devices, select **WiMERXXX** to connect.
- Connection may take a few seconds, once paired, instrument reading shows in the software.