


Important Notes

- Turn off the device after use. It will **NOT** turn off automatically.
- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.

Description

- ① **Sensor Connector** – connect to Mitutoyo linear gage with RM12BPE-6PH connector
- ② **Tri-Color LED**
 - – Device is on
 - – Device is in charge
 - – Device is fully charged
- ③ **Charge Port** – connect to cable to charge WiMER3
- ④ **On/Off Button** – press to turn WiMER3 on/off



Included in the box

- WiMER3 Base 1X
- USB Charging Cable 1X
- USB Power Adapter 1X
- User Guide 1X

Compatible Software

- iOS: MultiGage Reader (download for FREE from the App Store)
- Android: MultiGage Reader (download for FREE from the Play Store)
- Windows: MultiGage Reader (BLE dongle required, download for FREE from www.motionics.com Go to Resources > Download > Software)



MultiGage Reader App
iPhone/iPad

MultiGage Reader APP
Android



Quick Start

- Turn on your WiMER3 and connect it to a Mitutoyo linear gage.
- Plug in USB Bluetooth dongle if using Windows PC.
- Run the software, tap Scan/+ button to enter pairing page.
- Wait for the software to finish scanning nearby devices, select WiMERXXXX to connect.
- Connection may take a few seconds, once paired, WiMER3 reading shows in the software.