

⚠ Important Notes

- This test indicator turns off automatically if not used for 10 minutes.
- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.

Description

- ① **Battery Slot** – Use CR2032 coin battery to power this test indicator
- ② **MODE Button**
- ③ **FAVORITE Button**
- ④ **SET Button**



Product Page

Included in the box

- Test Indicator 1X
- CR2032 Battery 1X
- User Guide 1X

Compatible Software

- iOS: MultiGage Reader (download for FREE from the App Store).
- Android: MultiGage Reader (download for FREE from the Play Store).
- Windows: MultiGage Reader (BLE dongle required, download for FREE from www.motionics.com Go to Resources > Download > Software).



MultiGage Reader App
iPhone/iPad

MultiGage Reader App
Android



Quick Start

- Insert CR2032 battery into battery slot for a first-time use.
- Turn on Bluetooth on the test indicator.
 - Press MODE button 3 times and bt will appear on the screen.
 - Press FAVORITE button once to make sure On is selected.
 - Press SET button once to return to reading and Bluetooth icon will blink.
- Plug in USB Bluetooth dongle if using Windows PC.
- Run software (refer to compatible software section for download, and launch).
- For a first-time use, device activation is required using code printed on device.
 - On iOS, go to New Measurement>More>Setting>Custom Codes field, enter activation code, press Back then Save.
 - On Android, go to Menu>Settings>Custom Codes field, enter activation code, press Back then Save.
 - On Windows, go to Settings>Activation>Custom Activation Codes, enter activation code, press Add Code then Save.
- Tap Pair button in software to enter pairing page.
- Wait for the software to finish scanning nearby devices, then select SY308 to connect.
- Connection may take a few seconds. Once paired, readings show in software.